

по вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72 Астана +7(7172)727-132 Белгород (4722)40-23-64 Брянск (4832)59-03-52
Владивосток (423)249-28-31 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73
Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Казань (843)206-01-48
Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04
Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Орел (4862)44-53-42
Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Пермь (342)205-81-47 Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78
Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Тверь (4822)63-31-35
Томск (3822)98-41-53 Тула (4872)74-02-29 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59
Уфа (347)229-48-12 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Ярославль (4852)69-52-93

единый адрес: dbk@nt-rt.ru

Semi-Rugged Notebook

User's Manual



durabook.nt-rt.ru

DURABOOK SA14

Table of Contents

COPYRIGHT	4
REGULATORY STATEMENT	4
<i>Federal Communications Commission Statement</i>	4
<i>Declaration of Conformity</i>	4
<i>RF exposure warning</i>	5
<i>Canada, Industry Canada (IC) Notices</i>	5
<i>Battery Disposal</i>	6
<i>CLASS 1 LASER PRODUCT</i>	6
BEFORE YOU START	8
PACKAGE CONTENTS	8
COMPONENTS	9
<i>Front View</i>	9
<i>Back View</i>	10
<i>Left View</i>	11
<i>Right View</i>	12
<i>Rear View</i>	13
<i>Status Indicators</i>	14
GETTING STARTED	15
POWERING UP YOUR NOTEBOOK	15
<i>Connecting the AC Adapter</i>	15
<i>Using Battery Power</i>	15
INSTALLING THE BATTERY.....	16
<i>Charging the Battery</i>	16
<i>Charging Time</i>	16
<i>Checking the Battery Level</i>	17
<i>When to replace the Battery Pack</i>	17
<i>Removing the Battery</i>	18
<i>Installing the Second Battery (Optional)</i>	19
<i>Checking the Battery Pack Power Level</i>	20
STARTING YOUR NOTEBOOK	21
<i>Turning On Your Notebook</i>	21
<i>Shutting Down Your Notebook</i>	21
USING THE KEYBOARD	22
USING THE QUICK MENU	24
CONFIGURING THE SETUP MENU SETTINGS	25
<i>Configuring Hotkey</i>	26
<i>Configuring Stealth Mode Button Setting</i>	27
USING THE MEMORY CARDS	28
<i>Inserting a Memory Card</i>	28
<i>Removing a Memory Card</i>	28

USING THE SMART CARD	29
<i>Inserting a Smart Card</i>	29
USING THE PC CARDS	30
<i>Inserting a PC Card</i>	30
USING THE OPTICAL DISK DRIVE	31
<i>Placing a Disc</i>	31
USING THE FINGERPRINT SCANNER	32
<i>Initial Setup</i>	32

CONNECTING TO WIRELESS CONNECTIONS..... 37

CONNECTING TO A WIRELESS WIDE AREA NETWORK (WWAN)	37
---	----

USING THE BIOS SETUP UTILITY..... 39

BIOS SETUP MENU	39
STARTING THE BIOS SETUP UTILITY	39
NAVIGATING AND ENTERING INFORMATION IN BIOS.....	40
MAIN MENU	41
ADVANCED MENU	41
BOOT MENU	42
SECURITY MENU	42
SAVE & EXIT MENU	43

Copyright

Copyright© 2013. All rights reserved.

No part of this user manual may be transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of the manufacturer. Information is subject to change without prior notice.

Regulatory Statement

Federal Communications Commission Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interconnect cables and shielded AC power cable must be employed with this equipment to insure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

Declaration of Conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

SAR Value: 0.317W/kg

This device is operation in 5.15 – 5.25GHz frequency range, then restricted in indoor use only, Outdoor operations in the 5150~5250MHz is prohibit.

This device is slave equipment, the device is not radar detection and not ad-hoc operation in the DFS band.

Canada, Industry Canada (IC) Notices

This Class B digital apparatus complies with Canadian ICES-003 and RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

This device has been evaluated for and shown compliant with the IC Specific Absorption Rate ("SAR") limits when installed in specific host products operated in portable exposure conditions.

Canada, avis d'Industry Canada (IC)

Cet appareil numérique de classe B est conforme aux normes canadiennes ICES-003 et RSS-210.

Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférence et (2) cet appareil doit accepter toute interférence, notamment les interférences qui peuvent affecter son fonctionnement.

Informations concernant l'exposition aux fréquences radio (RF)

La puissance de sortie émise par l'appareil de sans fil est inférieure à la limite d'exposition aux fréquences radio d'Industry Canada (IC). Utilisez l'appareil de sans fil de façon à minimiser les contacts humains lors du fonctionnement normal.

Ce périphérique a été évalué et démontré conforme aux limites SAR (Specific Absorption Rate – Taux d'absorption spécifique) d'IC lorsqu'il est installé dans des produits hôtes particuliers qui fonctionnent dans des conditions d'exposition à des appareils portables.

Battery Disposal

THIS PRODUCT CONTAINS A LITHIUM-ION OR NICKEL-METAL HYDRIDE BATTERY. IT MUST BE DISPOSED OF PROPERLY. CONTACT LOCAL ENVIRONMENTAL AGENCIES FOR INFORMATION ON RECYCLING AND DISPOSAL PLANS IN YOUR AREA.

CLASS 1 LASER PRODUCT

LASERSCHUTZKLASSE 1 PRODUKT TO EN60825

CAUTION: THIS APPLIANCE CONTAINS A LASER SYSTEM AND IS CLASSIFIED AS A "CLASS 1 LASER PRODUCT." TO USE THIS MODEL PROPERLY, READ THE INSTRUCTION MANUAL CAREFULLY AND KEEP THIS MANUAL FOR FUTURE REFERENCE. IN CASE OF ANY TROUBLE WITH THIS MODEL, PLEASE CONTACT YOUR NEAREST "AUTHORIZED SERVICE STATION." TO PREVENT DIRECT EXPOSURE TO THE LASER BEAM, DO NOT TRY TO OPEN THIS ENCLOSURE.

ANNEX IV

Symbol for the marking of electrical and electronic equipment

The symbol indicating separate collection for electrical and electronic equipment consists of the crossed-out wheeled bin, as shown below. The symbol must be printed visibly, legibly and indelibly.



CAUTION FOR ADAPTER

THE SA14IT SEMI-RUGGED NOTEBOOK IS FOR USE WITH DEDICATED AC ADAPTER (DC +19V, 90W).

BATTERY SAFETY

DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISPOSE OF USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.

CAUTION FOR RJ-45

The RJ-45 jack is not used for telephone line connection.

Before You Start

Congratulations on your purchase of this notebook.

This rugged notebook is portable and provides users with maximum mobile computing experience in a wide range of working environments. Before you begin using your notebook, read this chapter to familiarize yourself with the main components installed in the system.

Package Contents

If any of following items is damaged, please contact your retailer.



Notebook



Power cord



DC 19V 90W power adapter



Standard 9-cell Li-ion Battery



NOTE

- The pictures are for reference only, actual items may slightly differ.

Components

Front View




No.	Item	No.	Item
1	LCD cover latch	9	Waterproof Keyboard
2	1.3M CCD camera	10	Touch pad
3	Display screen	11	Touch pad button
4	Stealth mode/night vision button	12	Fingerprint scanner
5	Quick menu button	13	Device Indicators (Power, Wireless, HDD, Caps Lock, Num lock, Battery)
6	Programmable button	14	Speaker
7	RF button	15	Microphone
8	Power button		

Back View



No.	Item
1	Docking connector
2	Battery latch
3	HDD latch release button
4	HDD latch
5	6-cell Battery / 2.5" SATA HDD compartment

Left View




No.	Item
1	ODD cover latch
2	Eject button
3	Pin Hole Eject
4	USB 3.0 ports (x2)
5	Microphone jack
6	Earphone jack

Right View



No.	Item
1	Battery compartment
2	Battery latch
3	PC Card slot
4	Card reader
5	USB 2.0 ports (x2)
6	RJ-45 port
7	Smart card reader

Rear View










No.	Item
1	Kensington lock slot
2	HDMI output port
3	VGA port
4	RS-232 port
5	DC-in jack

Before You Start

Status Indicators

The status indicators in the bottom left corner of the notebook light up when a particular function of the notebook is active. Each indicator is marked with a symbol.



Icon	Item	Description
	Power	The LED always lights on (blue) when the system is running. When the system is in sleep mode, the LED blinks.
	RF	Indicate the status of RF (WLAN, WWAN, or Bluetooth) communication. The LED always lights on (blue) when the function is enabled.
	HDD	A blinking HDD LED indicates HDD activity (data is being read or written).
	Num Lock	Lights on when Num Lock is activated.
	Caps Lock	Lights on when Caps Lock is activated.
 	Battery	Indicate the battery status: <ul style="list-style-type: none">• Green light means the battery is fully charged or the charging current is 0 for more than 3 minutes with the battery capacity higher than 95%.• Blinking green light means the system is calibrating the battery.• Orange light means the battery is being charged.• Blinking orange light means the battery is being charged but the battery temperature is out of charging range (0~60°C), the battery is being charged for more than 10 hours, or the charging current is 0 for more than 3 minutes with the battery capacity lower than 85%.• Blinking red light means the battery power is low (less than 7%).

Getting Started

This chapter will guide you on how to use your notebook.

Powering Up Your Notebook

Your notebook can be powered up using the AC adapter or the Lithium-ion battery.

Connecting the AC Adapter

The AC adapter powers up your notebook and charges the battery.



1. Connect the AC adapter to the DC-in jack of your notebook.
2. Connect the AC adapter to the power cord.
3. Plug the power cord to an electrical outlet.

Using Battery Power

1. Install a charged battery in the battery compartment.
2. Remove the AC adapter (if plugged). Your notebook will automatically use the battery power.



NOTE

- If you are using the notebook with the battery power for the first time, be sure that the battery is fully charged before you operate the notebook.

Installing the Battery

To install the battery, follow the steps below:

1. Insert the battery to the battery compartment.
2. Push completely until the battery locks into place.
3. Slide the battery latch to the lock position to secure the battery.



Charging the Battery

The Lithium-ion battery is not fully-charged upon purchase.

To charge the battery, follow the steps below:

1. Install the battery to your notebook. See procedures above.
2. Connect the AC adapter to the DC-in jack of your notebook.
3. Connect the AC adapter to the power cord.
4. Plug the power cord to an electrical outlet.

Charging Time

Number of battery pack	Charging duration (at 25°C)
1	4 hours
2 (*optional)	7 hours



NOTE

- The charging time may be longer if you are using your notebook while charging the battery.

CAUTION

- DO NOT charge the battery if the temperature is below 0°C or higher than 60°C.
- Use only the supplied AC adapter. Using other AC adapters may damage the battery or your notebook.


Checking the Battery Level

It is important that you monitor the battery status regularly to ensure you do not run out of power at a critical moment.

To check the remaining battery power, double tap the battery icon in the system tray.



The battery screen appears:

**When to replace the Battery Pack**

The battery performance gradually decreases over time and usage. We recommend you to replace your battery pack after 18 to 24 months of usage.

Getting Started

Removing the Battery

To remove the battery, follow the steps below:

1. Slide the battery latch to the unlock position.



2. Slide the battery latch to the right (as shown in the illustration) and hold it in place. Then pull the battery out to disengage it from its compartment.



3. Remove the battery out of the battery compartment.



Installing the Second Battery (Optional)

To remove the second battery, follow the steps below:

1. Align and insert the second battery to the hard disk compartment.



2. Press and hold the HDD latch release button to slide the HDD latch to the lock position.



Getting Started

Checking the Battery Pack Power Level

You can check the battery level by pressing the *Battery Check* button.



The remaining battery power is indicated by the four **Green** LEDs.


Green LED status	Battery Capacity Status
1st LED lights up	$0\% \leq 25\%$
1st and 2nd LED light up	$25\% \leq 50\%$
1st, 2nd, and 3rd LED light up	$50\% \leq 75\%$
All four LEDs light up	$75\% \leq 100\%$

Starting Your Notebook

Turning On Your Notebook

1. To open the display panel, unlock the LCD Cover latch to open the LCD.




2. Lift the cover lid up to upright position.
3. Press the  button until the Power LED lights up.

Shutting Down Your Notebook

It is important to properly shut down your notebook to avoid the loss of unsaved data. To shut down your notebook, do the following:

Tap **Start** > **Shut down**.

Wait for your notebook to turn off power completely before removing the power source (if necessary).




Using the Keyboard






No.	Keys	Description
1	Function keys	These function keys are used to perform designated tasks. The tasks for each key may vary from one application to another.
2	[Fn]	Press the [Fn] key in combination with other keys to execute a command.
	[Fn] + F1	Toggles the touch pad to on/off.
	[Fn] + F2	Switches to suspend mode.
	[Fn] + F5	Toggles between LCD, External display, or both.
	[Fn] + F6	Decreases the brightness level.
	[Fn] + F7	Increases the brightness level.
	[Fn] + F8	Decreases the volume by one level.
	[Fn] + F9	Increases the volume by one level.
	[Fn] + F10	Turns on or mutes the volume.
[Fn] + F12	Toggles the keyboard backlight on/off. (Backlight keyboard is optional)	
3	Windows key	Press to display the Start menu. This action is the same as clicking the Start icon.
4	Numeric keypad	Press the Num lock key to activate the numeric keypad. Press the keys on the numeric keypad to enter numbers or operands as you would on a calculator.


5	Application key	Press to display an application shortcut menu. This action is the same as right-clicking a mouse button.
---	-----------------	--

Using the Quick Menu

Press the  button to enter the Quick menu:



No.	Item	Description
1	Airplane mode	<p>Click the icon to enable/disable airplane mode.</p> <p> NOTE</p> <ul style="list-style-type: none"> When the Airplane mode is enabled, the wireless network (WLAN and WWAN), and Bluetooth will be automatically disabled.
2	WLAN	Click the icon to enable/disable the Wi-Fi (WLAN) function.
3	WWAN	Click the icon to enable/disable the WWAN function.
4	Bluetooth	Click the icon to enable/disable the Bluetooth function.
5	Setup	<p>Click the respective tab to set hotkey and stealth mode button settings.</p>  <p>For details, refer to "Configuring the SETUP Menu Settings".</p>

No.	Item	Description
6	Information	Click the icon to view the battery charge cycle, Bios version, EC version, and Quick Menu version. 




NOTE

- If the icon is gray (i.e. ) , this indicates the current function is disabled.

Configuring the SETUP Menu Settings

In Quick Menu, you can set the following settings via Setup menu:




- Programmable button (Hotkey)
- Stealth mode button


Getting Started

Configuring Hotkey

Click the **Programmable Button** tab to configure the **P** function button.



- To assign an application to the **P** button, do the following:
 - I. Select **Function setting for Hotkey**.
 - II. Click the folder icon () to set up an application for the **P** button.
 - III. Select the desired application and tap **Open**.



Configuring Stealth Mode Button Setting

Click the **Stealth Mode Button** tab to specify the Stealth mode button function.



There are two available functions:

- **Stealth mode:** Turn off the LCD backlight, LEDs (LED indicators and keypad backlight), speakers, camera flash, and RF devices.
- **Night vision mode:** Adjust the brightness of the LCD under 1.7 nits and turn off the LEDs (LED indicators and keypad backlight) and camera flash.

Using the Memory Cards

Your notebook supports different types of memory cards to provide faster data transfer. Supported types are as follows:

- SD card
- SDHC card
- Mini-SD card (with adapter)

Inserting a Memory Card

1. Pull to open the I/O port cover.



2. With the label side down, push the memory card into the memory card slot until it clicks into place.




Removing a Memory Card

It is important to remove the memory card properly. Improper removal may cause the data in the memory card to be corrupted and your notebook to malfunction.

To properly remove the memory card, follow the steps below:

1. Tap the removable disk icon on the system tray.
2. Tap **Eject SD Disk Device**.
The system confirms that the device can be safely removed.
3. Push the memory card to eject it.
4. Pull the card out from the slot.



Using the Smart Card

Inserting a Smart Card

1. Pull to open the I/O port cover.



2. Insert a smart card into the smart card slot.



Using the PC Cards

Inserting a PC Card

1. Pull to open the I/O port cover.



2. Insert a PC card firmly into the PC card slot until it clicks into the connector.



 **NOTE**

- The SA14iT semi-rugged notebook only supports 32-bit PCMCIA card.

Using the Optical Disk Drive

You can use to play or record DVD or CD disc.

Placing a Disc

1. Slide latch to the right to open the ODD cover.



2. Press Eject button to eject the tray.



3. Place the disc on the tray.
4. Close the disc tray.

Manual Ejection

If the **Eject** button fails to work properly, insert a paper clip into the **Pin Hole Eject** to open the tray.



NOTE

- Be sure that the notebook is turned off before performing the manual ejection.

Using the Fingerprint Scanner

This notebook supports **BioExcess** application that enables you to protect your notebook from unauthorized access, hide the encrypted private files, set the auto-login to your favorite websites, or launch an application by simply swiping your finger on the fingerprint scanner.

Initial Setup

1. Swipe your finger on the fingerprint scanner. The Initial Wizard appears on the screen.



2. Tap **Next** to continue.
3. Swipe your finger on the fingerprint scanner to practice enrollment or tap **Next** to skip this step.



4. Create a Windows password and click **Next** to continue.
You will be prompted to enter this password every time you log on.




5. Click one box to enroll your fingerprint and click **Next** to continue.



Getting Started

6. Swipe your selected finger on the fingerprint scanner for three times.




7. After you have completed the enrollment, a "Succeeded" message appears on the screen.



8. Repeat step 5~7 to enroll another fingerprint or click **Next** to continue.



9. The Secure Drive configuration may take a while to complete.




Getting Started

10. Click **Finish** to complete the initial setup of BioExcess.
To directly launch **BioExcess** application, click **Launch Control Center** checkbox.



NOTE

- You can also launch the **BioExcess** application by tapping **Start > BioExcess**.



11. Tap the respective option and configure the necessary settings.



Connecting to Wireless Connections



You can connect your notebook to a wireless local area network, WWAN, or Bluetooth.

Before using a wireless built-in device, you need to turn the respective built-in wireless functions on.


Connecting to a Wireless Wide Area Network (WWAN)

With **WWAN** function, it allows your notebook to connect to the Internet using mobile or cellular data networks.

To enable the function, follow the steps below:

1. Insert a valid SIM card into the SIM card slot.
2. Press the  button to open the Quick menu.
3. Tap the WWAN icon () to turn on the WWAN function.



4. Launch **AirCard Watcher** application.
 - On Windows desktop, tap "AirCard Watcher" (.
 - Tap **Start** > **AirCard Watcher**.
5. Tap **Connect** to enable the Internet connection via mobile data network.



Connecting to Wireless Connections

6. To disconnect the connection, tap

Disconnect.



NOTE

- Turn off the notebook before you insert the SIM card.



Using the BIOS Setup Utility

Your notebook has a BIOS setup utility which allows you to configure important system settings, including settings for various optional functions of the notebook. This chapter explains how to use the BIOS setup utility.

BIOS Setup Menu

The BIOS Setup Utility allows you to configure your notebook basic settings. When you turn your notebook on, the system reads this information to initialize the hardware so that it can operate correctly. Use the BIOS setup utility to change your notebook start-up configuration. For example, you can change the security and power management routines of your system.

Starting the BIOS Setup Utility

You can only enter the BIOS setup utility as the notebook is booting, that is between the time you turn on the notebook and before the Windows interface appears.

If your notebook is already on, shut down your notebook completely (power off) and restart it and then press the **F2** button to enter the setup utility.

Navigating and Entering Information in BIOS

Use the following keys to move between fields and to enter information:

Keyboard	Description
← →	Selects screen.
↓ ↑	Moves up/down to select items.
Enter	Confirms the selection and enters the selected menu screen.
+ / -	Changes an option for the selected items.
F1	Displays the Help screen.
F2	Invokes the previous values.
F3	Loads optimized default values.
F4	Saves the changes and exits Setup.
Esc	Exits any section. If you wish to exit the BIOS utility without saving changes or go to the main menu, then press this key.

Users are allowed to enter new values to replace the default settings in certain fields, and the rest of the fields are specified by system default parameters and cannot be modified by users. Reverse the attribute of the main options and press the **Enter** button to enter into the submenu. Press the **Esc** button to return to the previous configuration page.


Main Menu

The Main menu displays the system overview information about BIOS version, system information, and total memory size. You can also set the system date and time.




Advanced Menu

The Advanced menu allows you to select SATA mode, set the device to wake up on LAN when the AC power adapter is connected, enable/disable VPro function, calibrate fan and battery, and configure RF, Intel Rapid Start Technology, and Trusted Computing settings.




Boot Menu

The Boot menu allows you to configure the boot settings and boot sequence.




Security Menu

The Security menu allows you to set or change the Administrator and User passwords, configure Secure Boot settings, and set HDD password.



Save & Exit Menu

The Save & Exit menu allows you to save or discard the changes, restore the default values for all setup options before leaving the BIOS Setup Menu, and configure boot override sequence.



по вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72 Астана +7(7172)727-132 Белгород (4722)40-23-64 Брянск (4832)59-03-52
 Владивосток (423)249-28-31 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Казань (843)206-01-48
 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04
 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Липецк (4742)52-20-81
 Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Орел (4862)44-53-42
 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Пермь (342)205-81-47 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78
 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Тверь (4822)63-31-35
 Томск (3822)98-41-53 Тула (4872)74-02-29 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Ярославль (4852)69-52-93

единый адрес: dbk@nt-rt.ru